

PRESSURE RECORDER W/LCD DISPLAY

Features

- Large, backlit LCD display
- Front keypad w/lock feature
- Standard ¹/₄" NPT fitting
- High speed download
- Real-time operation
- User-selectable measurement units
- N.I.S.T. traceable calibration
- Min./max. & average statistics
- Programmable start/stop time
- Convenient status indicators
- User replaceable batteries

Applications

- Precision Pressure Recording
- HVAC
- Medical/Pharmaceutical
- Environmental studies
- Replace costly strip chart recorders
- Geothermal

The PR2000 is a battery powered pressure recorder, with an LCD display. It is perfect for applications requiring display pressure readings and a logger.


The 8-button keypad and large LCD provide convenient access to current data and recorder setup. Additionally, memory and battery levels, external power status, and sampling and recording status are shown on the LCD.



Available on-screen data includes: statistics (min, max, average); recording status (start, stop and recording rate); display options (units, text size); and calibration information (date calibrated, date for recalibration). Statistics can be cleared at any time during logging.

With 262,143 readings, the PR2000 has one of the largest memory capacities of any similar data recorder on the market. The non-volatile memory will retain recorded data, even if battery power is lost.

N.I.S.T. traceable calibration is available for users needing to meet regulatory requirements. Creating permanent records, performing data calculations, and the graphing of data is quick and easy: Simply connect the interface cable to an available USB port and, with a few clicks of the mouse, data is downloaded and ready for review or export to Excel[®].



MadgeTech Data Recorder Software

displays pressure and temperature data in an easy to use graph.

The Windows[®]-based software package allows the user to effortlessly collect, display and analyze data. A variety of powerful tools allow you to examine, export, and print professional looking data with just a click of the mouse.

PR2000 SPECIFICATIONS*

Pressure Sensor:	Semiconductor strain gauge	Reading Rate:	1 reading every 2 seconds to 1 every 24 hours
Pressure Range:	0 to 30, 100, 300 and 500PSIA/G;	Calibration:	Digital calibration through software
	0 to 1000 and 5000PSIA	Calibration Date:	Automatically recorded within device
Pressure Resolution:	0.002, 0.005, 0.02, 0.05PSIA/G;	Battery Type:	6 alkaline AA batteries
-	2% FSR, 0.25% @ 25°C typical	Battery Life:	1 year battery life at 1 minute reading rate with display off. 30 days typical with continuous display use. Optional AC
Pressure Response Time:	0.1 ms (10 to 90% FSR)		adapter available.
DOT-MATRIX LCD		Data Format:	PSIG, inHg, mmHg, bar, atm, Torr, Pa, kPa, MPa
Dimensions	2.5″ x 1.375 (63mm x 35mm)	Time Accuracy:	±1 minute/month (at 20° to 30°C)
Text	Configurable channel text size	Computer Interface:	USB (interface cable required); 115,200 baud
Indicators	Power, status, memory	Software:	XP SP3/VIsta/Windows 7
Backlight	Configurable w/auto shut-off and contrast adjustment	Operating	-20 to +60°C, 0 to 95%RH non-condensing
Start/Stop Time:	Software programmable start time and	Dimensions:	5.1" x 4.8" x 1.78" (130mm x 122mm x 45mm)
	date, up to six months in advance;	Weight:	40 oz (1134 g)
Memory	262,143 total readings; software configurable memory wrap	Enclosure:	Black anodized aluminum case/NPT Steel
		Approvals:	CE
SOFTWARE FEATURES		BATTERY WARNING: RISK OF FIRE OR EXPLOSION. DO NOT RECHARGE, FORCE OPEN, HEAT OR DISPOSE OF IN FIRE.	
	Simultaneously analyze data from several units or deployments; easily switch to a single data series	Statistic	cs: Calculate averages, min, max, standard deviation, and mean kinetic temperature with the touch of a button
	One click displays readings by time, value, parameter or sample number	Export Dat	a: Export data in a variety of common formats, or switch to Excel [®] with a single click
	Instantly access tabular view for detailed dates, times, values, and annotations	Calibratio	n: Automatically calculate and store calibration parameters
	Autoscale function fits data to the screen, or allows user to manually	Logger Configuratio	n: Easy set up and launch of data loggers with immediate or delayed start, preferred sample

enter their own values
Formatting Options: Change colors, line styles, plotting
options, show or hide channels quickly

Communications: Automatically sets up communications port, or lets user select configuration

rate, and device ID

*SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE. SPECIFIC WARRANTY AND REMEDY LIMITATIONS APPLY.

ORDERING INFORMATION

Model	Description	
PR2000-30	0-30PSIA(G) Pressure Recorder with LCD Display	
PR2000-100 0-100PSIA(G) Pressure Recorder with LCD Displa		
PR2000-300	0-300PSIA(G) Pressure Recorder with LCD Display	
PR2000-500	0-500PSIA(G) Pressure Recorder with LCD Display	
PR2000-1000	0-1000PSIA Pressure Recorder with LCD Display	
PR2000-5000	0-5000PSIA Pressure Recorder with LCD Display	
NIST	N.I.S.T. Calibration Certificate	
IFC200	Software, manual and USB interface cable	

ASK ABOUT OUR OTHER DATA RECORDERS			
Temperature	Pulse/Event/State		
Humidity	Low Level Current		
Pressure	Low Level Voltage		
рН	RF Transmitters		
Level	Intrinsically Safe		
Shock	Spectral Vibration		
LCD Display			



DOC-1154009-00 REV O 2012.01.11

