#### HI98115

# GroLine pH Tester

The HI98115 GroLine pH tester has been designed with many advanced features for growers of all types. This pH tester offers automatic calibration to one or two points, automatic buffer recognition, calibrated buffer tags, stability indicator, low battery indicator, and selectable automatic shut-off. With its compact size, one-button operation, and ease of calibration, the HI98115 is the optimal tool for pH measurement in nutrient solutions and soil slurries.

# Groline



# Replaceable pH Electrode

The HI1271 supplied gel filled pH electrode is 103 mm long and tapers to an 8 mm diameter at the sensing end. This narrow electrode easily fits into test tubes, vials, and other containers with small opening.

#### Economical

The HI98115 is a full-featured pH tester at a price that anyone that needs to measure pH can afford.

# High accuracy

The HI98115 GroLine pH tester features  $\pm 0.2$  pH accuracy with 0.01 resolution.

# Large LCD

Enhanced LCD that displays reading, stability indicator, low battery indicator and calibration tags.

#### **Automatic Calibration**

HI98115 is calibrated automatically to one or two points. The calibration buffers are automatically recognized and after calibration the buffer values used are shown on the display as a tag.

# Stability Indicator

An hourglass indicator is displayed on the LCD until a stable reading is obtained. Once a reading stabilized the indicator disappears and a reading can be recorded.

#### Automatic Shut-Off

The meter can be set to automatically turn off after 8 minutes or 60 minutes to conserve battery life in the event that the meter is left on. The auto off feature can be disabled.

## Long Battery Life

HI98115 has an exceptional long battery life of approximately 1000 hours. When the battery power is running low a low battery indicator is displayed.

## Plastic Carrying Case

HI98115 is supplied complete with meter, probe, calibration solutions and cleaning solutions packaged in a durable plastic carrying case.







The HI1271 pH electrode can be easily replaced. Just unscrew the electrode from the meter body and screw on a new one.



An easily removable cover provides access to the replaceable battery.



pH calibration can be performed directly in our solution sachets.

Specifications		HI98115
рН	Range	0.00 to 14.00 pH
	Resolution	0.01 pH
	Accuracy (@25°C/77°F)	±0.2 pH
	Calibration	automatic, one or two-point
	Electrode	HI1271 (included)
	Battery Type / Life	CR2032 Li-ion / approximately 1000 hours of continuous use
	Auto-off	8 minutes, 60 minutes, or can be disabled
	Environment	0 to 50°C (32 to 122°F); RH 95% max
	Dimensions	50 x174 x 21 mm (2 x 6.8 x 0.9")
	Weight	50 g (1.8 oz)
Ordering Information	<b>HI98115</b> is supplied with Hl1271 pH electrode, pH 4.01 buffer solution sachet (2), pH 7.01 buffer solution sachet (2), electrode cleaning solution sachet (2), battery, quality certificate, and instruction manual in a carrying case.	



# Plastic Carrying Case

HI98115 is supplied complete with meter, probe, calibration solutions and cleaning solutions packaged in a durable plastic carrying case

