

FRIDGE OR FREEZER THERMOMETERS

Ø52 mm dial thermometer



This easy to read fridge/freezer thermometer has a Ø52 mm dial that indicates temperature over the range of -30 to 30 °C in 1 °C divisions.

The unit incorporates colour-coded zones for ease of reading. The fridge/freezer thermometer is housed in an ABS case that incorporates a plastic hook to hang from a shelf.

| Order code | Description |
|------------|-------------------------|
| 800-100 | Ø52 mm dial thermometer |
| 800-101 | Ø52 mm dial - box of 20 |

Ø70 mm dial thermometer



This fridge/freezer thermometer has a Ø70 mm dial that indicates temperature over the range of -30 to 30 °C in 1 °C divisions. The unit incorporates colour-coded zones for ease of reading.

The fridge/freezer thermometer is housed in an ABS case measuring 60 x 70 mm and can be free-standing or hung from a shelf.

| Order code | Description |
|------------|-------------------------|
| 800-000 | Ø70 mm dial thermometer |
| 800-001 | Ø70 mm dial - box of 10 |

FoodSafe fridge thermometer

Most traditional temperature measuring devices in fridges only measure the air temperature. This is a major problem because cold air is heavier than warm air and therefore 'drops out of the fridge' the moment the door is opened.

The FoodSafe food simulant thermometer on the other hand is an encased thermometer that ensures it indicates temperature similar to that of the food stored in the fridge or chill cabinet. Ideal for commercial use, as it is reliable, robust and hygienic.

The unit indicates temperature over the range of -25 to 40 °C with an accuracy of ±1 °C over the range of -5 to 20 °C, 2 °C thereafter.

Each FoodSafe measures Ø25 x 150 mm and is supplied with a stainless steel hook for hanging in a fridge or cold cabinet.



| Order code | Description |
|------------|----------------------|
| 803-900 | FoodSafe thermometer |

Ø50 mm dial thermometer



This stainless steel, fridge/freezer thermometer has a Ø50 mm dial that indicates temperature over the range of -30 to 30 °C in 1 °C divisions.

The colour-coded area indicates when the thermometer is at the correct temperature for a fridge or freezer. The stainless steel housing measures 60 x 70 mm and can be free-standing or hung from a shelf.

| Order code | Description |
|------------|-------------------------|
| 800-923 | Ø50 mm dial thermometer |